



Traction Unit Traction Unit







Traction Unit Traction Unit

	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
Filter	rs				
10	R86-3010	108046, 281370, 522972, 549587, 549597, 925023	Baldwin Hydraulic Oil Filter	1	
11	R42-9030	550556, 554011	Baldwin Oil Filter - Engine	1	
12	R33-1300	148077, 502619, 838558	Baldwin Filter - Air Element	1	
12	RRF10201	148077, 502619, 838558	SilverGuard Air Filter	1	
13	R550489	1523143560, 1523143563, 5001190, 550489	Baldwin Fuel Filter	1	
13	RRF10517	550489	SilverGuard Fuel Filter	1	
14	R8-2329	122089	Air Cleaner - w/Pre Cleaner	1	
Belts					
20	R390994	390994	Belt - Reel Pump	1	
Tires					
40	R122367	122367	Wheel	2	
	Tech Note: Front:				
	Detail Description: Ir	ncludes Valve Stem:			
41	R121704	121704	Wheel - with Valve Stem	1	
	Tech Note: Rear:				

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.





Traction Unit Traction Unit

	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
42	R232-27	232-27, 360111	Stem - Valve w/ Cap	3	
Gaug	es and Controls				
60	R33-0990	107917	Meter - Amp	1	
61	R162723	162723, 358825	Meter - Hour	1	
62	R27-2360	1000348, 131095	Switch - Key 6 Lead 9/16 Mount	1	
63	R343060	343060, 5000039	Ignition - Key Set/2	1	
64	R395282	395282, 5000619	Clutch - Electric H.D.	1	
Othe	r Parts Available				
70	R131966	131966	Control - Throttle	1	
71	R364226	364226	Cable - Steering	1	
72	R345666	345666	Clamp	1	
73	R364902	364902	Clamp - Torsion Spring 1-3/8	1	
74	R348856	348856	Clamp - Muffler - 1-1/2	1	
75	R337358	337358	Axle - Steering	1	
76	R153244	153244	Cable - Battery Negative	1	
78	R364164	364164	Spring	1	
79	R501307	501307	Brake Assy	2	
	Detail Description: Includes: 2ea: R353868 Spring; 1 ea: R130191 Plate, R353869 Spring, R501150 Shoes, R546516 Camshaft & R554526 Lever:				
80	R554526	501151, 554526	Lever - Brake	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.





Traction Unit Traction Unit

	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
81	R353868	353868	Spring - Shoe Hold Down	4	
82	R130191	130191	Plate - Brake Support	2	
83	R546516	546516	Camshaft - Brake	2	
84	R353869	353869, 555714	Spring - Shoe Return	2	
85	R501150	501150	Shoe - Brake Set / 2	2	
86	R353914	353914	Bolt - Wheel	8	
87	R207461	207461	Drum - Brake	2	
88	R390742	390742	Shield	2	
89	R400184	400184, 400194	Screw - 5/16-18 x 3/4 Hex	8	
90	R446136	446134, 446136	Washer - Lock 5/16 Zinc	12	
91	R500596	500596	Tapered Bearing Set - Cup and Cone	2	
			·		