




Traction Unit Fuel Tank







Traction Unit Fuel Tank

| | R&R Part No. | OEM Part No. | Description | Qty Req | Order Quantity |
|----|-----------------|--|------------------------------------|------------|-------------------|
| 1 | R95-0576-03 | R95-0576 | Base-Tank, Fuel | 1 | |
| 2 | R240-11 | | Bushing - Rubber - Flanged | 4 | |
| 3 | R92-7186 | R77-0990 | Tank-Fuel | 1 | |
| 4 | R93-7170 | | Cap - Fuel w/Tether | 1 | |
| 6 | R24M7139 | | Washer - Flat 6mm | 1 | |
| 7 | R150778 | | Screw - Button HD Soc CS 10-24x3/8 | 5 | |
| 8 | R3296-39 | 3296-39, R32127-25, R32128-36, R3296-17, R3296-22, R915663P, R99-7443 | Locknut - 3/8-16 Nylon | 1 | |
| 9 | R323-6 | 323-6, R01-150-0010, R01-178-0608, R20-47-AD, R20-47-AGD, R3224-2, R49-3510, R908034P, R908332 | Bolt - Hex HD 3/8-16 x 1 GR5 YZ | 1 | |
| 10 | R63-8410 | R53-6380, R63-4810 | Washer - Isolator Bushing | 4 | |
| 11 | R240-9 | | Grommet - Rubber | 3 | |
| 12 | R86-7640G | | Box - Litter - Green | 1 | |
| 13 | R100-6435 | R56-7720 | Post - Battery - Stainless | 2 | |
| 14 | R92-5018-03 | R92-5018 | Clamp-Battery | 1 | |

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.





Traction Unit Fuel Tank

| | R&R Part No. | OEM Part No. | Description | Qty Req | Order Quantity |
|----|-----------------|---|---------------------------|------------|-------------------|
| 15 | R09030 | R32103-1, R32103-12, R32103-22 | Nut - Wing 1/4 | 2 | |
| 16 | R3256-22 | R09061, R24-9-BD, R3-1032, R93-0954, R93-0989 | Washer - Flat 1/4 Yellow | 2 | |
| 17 | R150931 | | Fitting - Hose | 1 | |
| 18 | R110-8151 | R92-7152 | Hose - Formed | 1 | |
| 19 | R2412-36 | R2210-87, R31-9140, R93-5818, R99-0772 | Clamp - Hose 1/2 | 2 | |
| 20 | R83-1390 | | Needle Valve - in Line | 1 | |
| 21 | R109-0294 | | Hose - Fuel | 1 | |
| 22 | R825619 | R108-3832, R108-3854, R821814, R83-1320, R832774, R94-2690, R95-2926, R99-9404 | Filter - Fuel | 1 | |
| 23 | R109-0302 | | Hose - Fuel | 1 | |
| 24 | R2412-73 | | Clamp - Rubber Coated | 1 | |
| 25 | R2412-98 | | Clamp - Spring - Hose 1/4 | 3 | |
| 26 | R3274-69 | R3274-91 | Screw - 1/4-20 x 3/4 Hsbh | 1 | |

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.





Traction Unit Fuel Tank

| | R&R Part No. | OEM Part No. | Description | Qty Req | Order Quantity |
|----|-----------------|--|-----------------------------|------------|-------------------|
| 27 | R301504 | R32127-24, R32146-17, R3296-16, R3296-42, R915661P, RM40333 | Locknut - ESNA 1/4-20 | 1 | |
| 29 | R86-7450 | | Cable - Ground | 1 | |
| 30 | R95-5825 | | Wire Assy | 1 | |
| 31 | R322-3 | R01-150-1420, R01-178-0506, R09109, R20-24-AD, R20-24-AGD, R48-9270, R513339, R908017P, RB311201 | Bolt - Hex HD 5/16-18 x 3/4 | 2 | |
| 32 | R3296-29 | 3296-29, R1-804256, R915662P | Locknut - 5/16-18 ESNA | 2 | |